

0002 Software DiSoft

The screenshot displays the DiSoft software interface. At the top, there is a menu bar with options: Öffnen, Start, Stopp, Referenzierung, Nadel Vermessen, Spülen, Wiegen, Teile=0. Below the menu bar, the file name 'Datei: Programm1.t' is shown. The main window is divided into several sections:

- DiSoft Programm Editor:** Shows a G-code program with coordinates (X, Y, Z) and various parameters.
- Parametersätze:** A table listing parameters and their values.
- DiSoft Optionen:** A settings window with various options like 'Referenzierung nach jedem Programmdurchlauf prüfen', 'Automatisches Spülen', and 'Nadelsensor N200'.
- Machine Status Display:** Shows the current position (X: -316.672, Y: 6.309, Z: 21.275) and other data like 'Zähler Gesamt: 48 Teile: 5' and 'Temperatur: 20.1° Feuchtigkeit: 34.3%'.

Beschreibung

Menügeführte Software DiSoft für Windows 11.

Frei programmierbar für die Dosierung von Punkten, Kreisbögen, Linien und Kombinationen über "Teach-In" oder Tastatureingabe. Programmierung von 12 Ein-/12 Ausgängen, Schleifen, Bedingungen.

Eingabe von verschiedenen Dosierparametern. Auswahl von Optionen wie z.B. Nadelsensor, Waage, Außentempersensoren, Barcodescanner, Kamera usw.

Erweiterte Funktionen wie Datenbank, Eingabe "User" oder speziell programmierbare Kundenwünsche sind möglich.